

Imagine the invisible

Industrial



Bobcat-1.7-320

Uncooled smart InGaAs camera


Smart and sharp imaging for reliable quality control

With superior image quality the Bobcat-1.7-320 is available as a complete digital infrared camera system with an embedded Digital Signal Processor (DSP) for intelligent real-time image processing reducing the overall cost. The very compact housing also allows for easy system integration.


In addition the Bobcat-1.7-320 comes with an analog and digital interface.

The camera interfaces to a PC via standard Ethernet or CameraLink connection.


With the Bobcat-1.7-320 NIR camera you can look through glass, so standard available C-Mount lenses and protective camera housings can be used. Again making this camera affordable for a wide variety of industrial applications.



Designed for use in




☛ Solar cell inspection



☛ Fluid level monitoring



☛ Stress analysis



☛ Waste sorting

Applications

- Waste sorting
- Food inspection
- On-line quality control
- Thermal imaging of hot objects (300°C to 800°C range)

Benefits & Features

- High sensitivity
- Flexible and easy-to-use
- Ethernet standard interfaces
- Fast time to market with easy integration
- Flexible programming in an open architecture

Broad range of accessories available to simplify your inspection


▶ Lens & filter options



▶ Inputs



▶ Software



- Xeneth basic
- Xeneth advanced (optional)
- Xeneth SDK (optional)
- Intelligent Quadrox Recording (optional)

▶ Outputs

Specifications

| Array specifications | Bobcat-1.7-320 |
|-------------------------------|---|
| Array Type | InGaAs |
| Spectral band | 0.9 μm to 1.7 μm |
| # Pixels | 320 x 256 |
| Pixel Pitch | 20 μm |
| Array Cooling | Uncooled |
| Gain setting | High gain: 10fF Low gain: 90 fF |
| Pixel operability | 99% |
| Camera Specifications | Bobcat-1.7-320 |
| Lens (included) | |
| Focal length | 16 mm f/1.4 |
| Optical interface | C-mount (Broad selection of lenses available) |
| Imaging performance | |
| Frame rate | 60 Hz in 8 bit mode 30 Hz in 16 bit mode |
| Integration type | Snapshot |
| Exposure time range | 7 μs - 70 ms (low gain) |
| S/N ratio | High gain: 62 dB Low gain: 69 dB |
| Interfaces | |
| Camera control | Ethernet (TCP/IP): Xeneth API/SDK CameraLink: XSP (Xeneth Serial Protocol) |
| Digital output | Ethernet (TCP/IP): 16 bit or 8 bit CameraLink: 16 bit base |
| Trigger | Trigger in; LVCMOS |
| Power requirements | |
| Power consumption | < 4.5 W at room temperature |
| Power supply | 12 V |
| Physical characteristics | |
| Camera cooling | Passive cooling |
| Ambient operating temperature | 0°C to 50°C |
| Humidity | Non-condensing |

Product selector guide

| Part number | Digital | Frame rate | Analog |
|-------------|---------|------------|--------|
| BO03C500 | ✓ | 60 | PAL |
| BO03C500N | ✓ | 60 | NTSC |

XB-033 issue 2 | Information furnished by Xenics is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. Specifications are subject to change without notice. This information supersedes all previously supplied information.